Setting the region



1. Press the **LEFT** arrow key to move cursor to **YES** and press the **OK** key to enter setup mode.



2. Press the **LEFT** arrow key to move cursor to **SATELLITE** and press the **OK** key to enter **SATELLITE** menu.



3. Press the **DOWN** arrow key and the **OK** key to enter **SET REGION** menu.



4. Press the arrow keys to select parameter you wish to edit and press the **OK** key to edit parameter. Press the **RETURN** key to save or abort and return to the main display.



5. Set the **CONTINENT.**
Press the **UP** and **DOWN** arrow keys to select the continent that you are in.
Press the **OK** key to set the **CONTINENT.**



6. Set the **REGION**.
Press the **UP** and **DOWN** arrow keys to select the region you are in.
Press the **OK** key to set the **REGION.**



7. Press the **RETURN** key to load the current setting or abort and return to the main display.



8. Setting is being loaded to the system.
The ACU will restart the system automatically after uploading the setting.
DO NOT turn off ACU power while uploading is being processed.



9. Region information has been updated.